



Loading the Calibration Files.

In the Odyssey software navigate to the 'set calibration data' window.



Click on the 'Import Files' button and navigate to the location of your calibration files. Note that some types of logger require two calibration files each.




Applying Calibration Settings


Once the calibration files have been loaded the settings will be applied automatically to any downloaded data.

If you wish to apply the settings to existing data, select the site file from the 'Site Files' list on the main screen to which you would like to apply the calibration data.

With the site file selected click on the 'Data Worksheet' tab and select the 'Data Block' to be calibrated.



Click 'Site\ReCalibrate Data Block' to apply the calibration settings to your data.



If the calibration settings are applied successfully the data in the 'Calibrated Value' column of the worksheet will be different to those in the 'Raw Value' column.

If the calibration settings have not been applied the raw values and calibration values will be the same. In this case check that the calibration files have the same serial number as the logger whose data you are trying to calibrate.